

IMPORTANT DAYLIGHT SAVING TIME (DST) INFORMATION

In August of 2005 the President signed the new Energy Bill into law. This bill contains many provisions intended to encourage energy conservation, explore alternative energy sources, and reduce our dependence on foreign oil.

One of the provisions of this bill calls for extending Daylight Saving Time (DST) starting in the year 2007. If nothing is done to change or rescind this provision, Daylight Saving Time (DST) will be revised as follows:

DST STARTING TIME

2006

First Sunday in April

2007

Second Sunday in March

DST ENDING TIME

2006

Last Sunday in October

2007

First Sunday in November

This SmartSet® Clock Radio was programmed at our factory to automatically adjust itself for the Daylight Saving Time (DST) schedule that has been in effect since 1966. Therefore in 2006 this SmartSet® Clock Radio will adjust itself automatically on the first Sunday in April and the last Sunday in October.


However, beginning in the year 2007 it will be necessary for you to adjust the Daylight Saving Time (DST) start and end dates to agree with the new law. You only need to make this adjustment one time and then your SmartSet® Clock Radio will automatically adjust itself for the new Daylight Saving Time (DST) changes until the end of this century.

The procedure for adjusting the Daylight Saving Time (DST) start and end dates in 2007 is as follows:

Adjusting the DST Start Date


- 1.) Depress and hold both the **MONTH/DATE** and **ALARM 1** buttons. After 3 seconds the display will show the DST 'start' month, week, and date.

The first digit will show the month ("4" = April) and the second digit will alternately show the week ("F" = First Week) and the date ("1" = April 1st).



This indicates that Daylight Saving Time (DST) will begin on the first Sunday in April as usual.

- 2.) While holding the **MONTH/DATE** and **ALARM 1** buttons press the **DOWN** or "–" Set button (depending on your specific model) three times until the display is showing "3" (March) as the month digit and the week/date digit is alternately flashing "F 2" (second week) and "11" (March 11th).




This indicates that Daylight Saving Time will begin on the second Sunday in March, which will be March 11th in 2007.

Adjusting the DST End Date


- 3.) Depress and hold both the **MONTH/DATE** and **ALARM 2** buttons. After 3 seconds the display will show the DST 'end' month, week, and date.

The first digit will show the month ("10" = October) and the second digit will alternately show the week ("L" = Last Week) and the date ("28" = October 28th).



This indicates that Daylight Saving Time (DST) will end on the last Sunday in October as usual.

- 4.) While holding the **MONTH/DATE** and **ALARM 2** buttons press the UP or "+" Set button (depending on your specific model) once until the display is showing "11" (November) as the month digit and the week/date digit is alternately flashing "F" (first week) and "4" (November 4th).



This indicates that Daylight Saving Time will end on the first Sunday in November, which will be November 4th in 2007.

Once you make the change for the new Daylight Saving Time (DST) schedule beginning in 2007 your SmartSet® Clock Radio will automatically adjust for the new schedule until the end of the century (2099).

NOTE: If the built in long life lithium battery is removed or replaced while the radio is not connected to the AC outlet all internal memory will be erased and the clock will return to its original default settings. After installing a new battery and resetting the clock to the correct year, date and time it will also be necessary to reset the Daylight Saving Time (DST) settings as described above.